

(1) Basisprofil montieren

Wir empfehlen, das Basisprofil zu verschrauben. Profil auf dem Untergrund ausrichten. Ausreichende Dehnungsfuge zum Bodenbelag berücksichtigen. Bohrlöcher anzeichnen und 5 mm Löcher bohren. Bohrstaub entfernen und Dübel in die Löcher stecken, so dass sie vollständig versenkt sind. Mit den beigelegten Schrauben wird das Basisprofil befestigt. Bei Holzuntergründen kann die Schraube direkt mit dem Untergrund verschraubt werden.

Alternativ: Basisprofil verkleben

Profil auf dem Untergrund ausrichten. Dehnungsfuge zum Bodenbelag beachten. Mit einem Stift das Basisprofil auf dem Untergrund anzeichnen. Zum Verkleben des Basisprofils einen 2-Komponenten-Kleber oder einen Kleber mit besonders hoher Klebkraft, z.B. Kleiberit verwenden. Überschüssigen Kleber mit einem Spachtel abziehen. Kleber vor der Befestigung des Oberprofils vollständig aushärten lassen.

(2) Oberprofil befestigen

Bodenbelag verlegen; dabei eine ausreichende Dehnungsfuge berücksichtigen. Anschließend wird das Oberprofil im Basisprofil fixiert. Oberprofil auflegen, so dass die Führungsstege über den Schraubkanal des Basisprofils greifen. Das Profil passt sich automatisch in der Höhe an.

(3) Torx-Schrauben auswählen

Es sind verschiedene Schraubenlängen beipackt. Korrekte Schraubenlänge auswählen.

(4) Oberprofil verschrauben

Schraubendreher oder Akku-Schrauber mit Bit-Torx (T10) verwenden. Der Akku-Schrauber sollte auf ein niedriges Drehmoment eingestellt sein, um ein Überdrehen der Schrauben zu vermeiden. Schrauben langsam im Schraubkanal befestigen.

(5) Demontage

Die Schrauben können mit einem Akku-Schrauber oder Schraubenzieher gelöst werden. Das Oberprofil kann später erneut im Basisprofil befestigt werden.

(1) Mounting the base section

We recommend screwing the base profile in place. Align the profile on the subfloor. Ensure sufficient expansion gap to the floor covering. Mark the drill holes and drill 5 mm holes. Remove drilling dust and insert the dowels into the holes so that they are fully countersunk. Secure the base profile with the included screws. For wooden subfloors, the screw can be driven directly into the subfloor.

Alternatively: Gluing the base section

Align the profile on the subfloor. Ensure sufficient expansion gap to the floor covering. Use a pencil to mark the position of the base profile on the subfloor. To glue the base profile, use a two-component adhesive or an adhesive with particularly high bonding strength, e.g., Kleiberit. Remove excess adhesive with a spatula. Allow the adhesive to fully cure before attaching the top profile.

(2) Lay on the top section

Lay the floor covering, ensuring sufficient expansion gap. Then, lay on the top section. Place the top section so that the guide ribs engage the screw channel of the base profile. The profile will automatically adjust its height.

(3) Select Torx screws

Various screw lengths are included. Select the correct screw length.

(4) Screw the top section in place

Use a screwdriver or cordless drill with a Torx (T10) bit. The cordless drill should be set to a low torque to prevent over-tightening the screws. Tighten the screws slowly in the screw channel.

(5) Disassembly

The screws can be loosened with a cordless drill or screwdriver. The top profile can later be reattached to the base profile.

