

Verlegehinweise

Laying instructions



Starke Verbindung
Kluge Technik
Strong contacts
Clever technology

Vorbereitung:

Wir empfehlen, Sockelleisten vor der Verlegung zu für 48 Stunden im Raum zu akklimatisieren, um Spannungsschäden zu vermeiden. Die Hartschaum-Sockelleiste wird durch nageln, klammern oder kleben an der Wand befestigt. Die Wand und der Boden sollten möglichst plan sein. Beginnen Sie zunächst an der Türzarge und arbeiten Sie im Uhrzeigersinn.

Zuschnitt der Sockelleisten:

Zum Ende oder an / in den Ecken ist die Sockelleiste mittels einer Stanze, Gehrungs- oder Kappsäge zu zuschneiden. Schneiden Sie stets nur die Leiste welche Sie auch direkt anmontieren wollen.

Befestigung der Leiste:

Bei der Befestigung drücken Sie die Leiste fest nach unten auf den Bodenbelag auf, so dass die Dichtlippe fest auf dem Bodenbelag aufliegt. Nageln Sie die Leiste ggf. mittels Stahlstiften, welche nicht rosten sollten, in einem Abstand von ca. 30 cm an. Wenn Sie es vorziehen die Leiste zu kleben, empfehlen wir einen Montagekleber mit hoher Anfangshaftung. Sie können auch ein doppelseitiges Klebeband verwenden. Die jeweiligen Innen- und Außenecken sowie Endkappen sollten Sie mit der Montage der Leiste direkt befestigen. Diese werden nur aufgesteckt.

Preparation:

We recommend acclimatizing the skirting boards inside the room for 48 hours before laying in order to avoid tension damage. The foamed skirting board is attached to the wall by nailing, clinging or gluing. The wall and the floor should be as levelled as possible. Begin by the door frame and work in a clockwise direction.

Cutting the skirtings:

At the end or at the corners, cut the skirting board using a punch, miter or chop saw. Always cut only the bars which you want to mount directly.

Attachment of the skirting:

When attaching, press the profile firmly down onto the floor covering so that the sealing lip rests on the floor covering. If necessary, nail the profile at a distance of approx. 30 cm using steel pins that should not rust. If you prefer to glue the strip, we recommend a mounting adhesive with high initial liability. You can also use a double-sided tape. The respective inner and outer corners as well as end caps should be fastened directly with the assembly of the strip. These are only plugged on.

