

## Verlegehinweise

### Laying instructions



Starke Verbindung  
Kluge Technik  
Strong contacts  
Clever technology

#### Einsatzbereich:

Das T-Cover- Profil wird für alle Hartbodenbeläge zur Fugenabdeckung eingesetzt. Dehn- oder Bewegungsfugen müssen laut VOB DIN 18 365 in den Oberbodenbelag übernommen werden. Das T-Cover-Profil ermöglicht es, dennoch eine geschlossene Oberfläche herzustellen.

#### Montage:

Füllen Sie die verbleibende Dehnungs- oder Bewegungsfuge zwischen den Bodenbelägen mit einem dauerelastischen Silikon- oder Montageklebstoff auf und drücken Sie das Profil mit dem Steg in die eingefüllte Masse. Beachten Sie dabei, dass das Profil planeben aufliegt.

#### Alternativ:

Legen Sie einen Silikon- oder Montageklebstoffstreifen einseitig an einen Steg des Profils an und kleben Sie das Profil an einer Bodenbelagskante über der Fuge an. Hierdurch können die Flächen vor allem bei schwimmenden Fußbodenkonstruktionen weiterhin frei agieren. Beachten Sie, dass das Profil planeben aufliegt.

#### Montagetiefe:

Die Mindestdicke des Bodenbelags entspricht der Untersteglänge des Profils.

#### Application:

T-Cover-profiles are used for all hard floor coverings to cover the joints. Expansion joints must be transferred to the top floor according to VOB DIN 18 365. The T-Cover-profile makes it possible to create a closed surface.

#### Assembly:

Fill the remaining expansion joint between the floor coverings with a permanently elastic silicone or mounting adhesive and press the profile with the bar into the filled compound. Please note that the profile lies flat.

#### Alternatively:

Apply a strip of silicone or mounting adhesive to one side of a bar of the profile and glue the profile to a floor covering edge right above the joint in the subfloor. As a result, the surfaces can continue to move freely, especially when the flooring is installed floatingly. Please note that the profile has to lie flat.

#### Mounting Depth:

The minimum thickness of the floor covering corresponds to the length of the bar on the underside of the profile.

