

Verlegehinweise

Laying instructions



Starke Verbindung
Kluge Technik
Strong contacts
Clever technology

Profil verlegen:

Zunächst werden die Setzstufen so gefliest, dass sie oben bündig mit der Trittstufe abschließen. Anschließend wird Fliesenkleber auf die Trittstufe aufgetragen. Das Profil wird so in das Klebebett gelegt, dass die überhängende Kante des Profils plan an der Fliese der Setzstufe anliegt. Nun kann die Trittstufe gefliest werden. Die Fliesen sollten oben bündig mit dem Treppenkantenprofil abschließen. Zwischen Fliese und Profil wird eine Fuge von ca. 2 mm belassen, die anschließend mit Fugenmörtel verfüllt wird.

Installing the profile:

First, the risers are tiled so that they are flush with the tread. Subsequently, adhesive is applied to the tread. The profile is placed in the adhesive so that the overhanging edge of the profile rests flat against the tile of the riser. Now the tread itself can be tiled. The tiles should be flush with the stair nosing profile at the top. Between tile and profile, a gap of about 2 mm is left, which is then filled with joint mortar.

