

Verlegehinweise

Laying instructions



Starke Verbindung
Kluge Technik
Strong contacts
Clever technology

Verwendung:

Diese Profile sind für die Verlegung von Spannteppichbodenbelägen konzipiert. Andere Bodenbeläge können auf diesen Profilen nicht Verlegt werden.

Montage:

Die Profile werden in der Regel mit einem zugfesten Klebstoff, z.B. einem Zweikomponentenklebstoff, nach Herstellerangaben auf dem Untergrund verklebt. Nach vollständiger Aushärtung des Klebstoffs kann der Spannteppichboden auf den Krallen des Profils aufgehängt und zu den Seiten ausgespannt werden.

Höhenanpassung:

Die Profile lassen sich in der Höhe zur Belagstärke anpassen. Nachdem der Bodenbelag in das Profil eingelegt wurde können die überdeckenden Schenkel heruntergedrückt und an die Belagoberfläche angepasst werden. Mit einem Schlagklotz, das Sie in Längsrichtung auf das Profil positionieren können Sie unter Zuhilfenahme eines Kunststoffhammers das Profil herunterschlagen. Bitte beachten Sie hierbei, dass die Schläge gleichmäßig verteilt ausgeführt werden, um eine Beschädigung des Profils zu vermeiden. Beim Herunterschlagen wird der Bodenbelag zusätzlich durch die Krallenhaken gegen Verrutschen gesichert.

Application:

These profiles are designed for the laying of fitted carpet floor coverings. Other floor coverings can not be inserted into these profiles.

Assembly:

The profiles are usually glued to the ground with a tensile adhesive, e.g. a two-component adhesive. Please consider the installation instructions of the manufacturer. After the adhesive is completely cured, the flooring can be hung onto the claws of the profile and stretched to the sides.

Height adjustment:

The profiles can be adjusted in height to the covering thickness. After the floor covering has been inserted into the profile, the overlapping legs can be pressed down and adapted to the surface of the covering. With a wooden support, which you can position longitudinally on the profile, you can knock down the profile with the help of a hammer. Please note that the strokes should be evenly distributed to avoid damaging the profile. When knocking down the flooring is additionally secured against slipping by the claw hooks.

