

Verlegehinweise

Laying instructions



Starke Verbindung
Kluge Technik
Strong contacts
Clever technology

Anwendung:

Der Eckschutzwinkel wird vor allem in Bereichen eingesetzt wo Patientenbetten oder Rollwagen durch Durchgänge geschoben werden, um das Ausschlagen von Mauerwerk oder Putz von den Ecken zu vermeiden.

Verkleben:

Bei der Verklebung des Profils auf dem Untergrund ist darauf zu achten, dass der Untergrund frei von Trennmitteln ist. Der Untergrund sollte möglichst trocken entsprechend den einschlägigen DIN-Normen sein. Der Winkel sollte nicht auf tapezierten Untergründen aufgebracht werden. Nutzen Sie zum Verkleben bitte starkklebende Montageklebstoffe. Tragen Sie den Klebstoff satt auf der Rückseite des Profils auf und drücken das Profil fest an die Wandecke an.

Application:

The corner protector is used primarily in areas where patient beds or trolleys are pushed through passages to prevent the breaking of masonry or plaster from the corners.

Gluing:

When gluing the profile to the surface, it must be ensured that the surface is free of release agents. The surface should be as dry as possible in accordance with the relevant DIN standards. The angle should not be applied to wallpapered surfaces. Please use strong mounting adhesives for gluing. Apply the adhesive on the back of the profile and press the profile firmly against the wall corner.

